

LONG RANGE SYSTEM GOLD DETECTOR



USER`S MANUAL
14 OF MAI 2004

Any information contained in these operating instructions may be changed without prior notice. OKM does not make any warranty for these documents. This also applies without limitation to implied assurances of merchantability and fitness for a specific purpose.


OKM does not assume any responsibility for errors in this manual or for any incidental or consequential damage or loss associated with the delivery, exploitation or usage of these documents.

This manual may not be copied, duplicated or translated into another language, neither in part nor completely, without the prior written consent of OKM.

With the Long Range System you can find gold until a distance of 3 km.

Important! The gold has to be in the ground for a long time to be recognized by this machine. You can only find very old gold (about 50 years old).

Long Range System



A Output headphones
B On and Off button
C Operational status indicator
D Signal lamp


E Battery box
F Antennas
G Hand grip

Use of the Long Range System

To use the Long Range System you have to power on the device with the power button. Do not forget to put the 9V battery in the box. The operational status indicator shows the ready status of the machine. By using the device the north direction have to be behind you. The figure shows exactly the way to use.

Hold the Long Range System in your hand and do your measurement from north to south. Move the System slowly up and down, how you can see in the figure. You can also move it from left to right and back. Until you can hear a sound from the device.

If the machine recognize gold then you can hear a sound and the blue lamp is shining. Keep this point in your mind.



During this proceed you have determined a direction where the gold found could be. But you don't know how far away it is. Therefore you have to do pin pointing. Walk about 50 meters to the left (or right) and repeat this procedure. There where the two directions cross is the place of discovery. Here you can see again the procedure of pin pointing.




Figure 1: pin pointing




figure 2: procedure